CIS009-2, MECHATRONICS CONTROL SYSTEMS

David Goodwin

Department of Computer Science and Technology University of Bedfordshire

15th November 2012



Outline

Mechatronics

Department of Computer Science and

Control systems Open-loop control Closed-loop control Example

2 System Responses PID controller Step Response

Matlab & Octave

Resources



David Goodwin

Open-loop control

System Response

PID controller

Matlah & Octavo

Resources

CONTROL SYSTEMS



Control system principles Block Diagrams

Mechatronics

David Goodwin

Control systems

Open-loop control


Closed-loop control

Example

System Respons PID controller Step Response

Matlab & Octav

- Electronic systems and circuits are often represented by block diagrams.
- Shorthand pictorial representation of the cause-and-effect relationship between the input and output in a real system.
- Characterise functional relationships between components.
- Not necessary to understand the functional details of a block to manipulate a block diagram.





Block Digram Basics

Mechatronics

David Goodw

Control sys

Open-loop control
Closed-loop control

System Response PID controller Step Response

Matlab & Octave

- The basic building block of a control system block diagram.
 - The transfer function block represents a portion of the system
 plant, sensor, controller, or pre-filter.

•
$$G(s) = \frac{Y(s)}{X(s)}$$

- G(s) must be a Linear Time-Invariant System (output does not depend explicitly on time).
- ullet G(s) is property of the system independent of the input to that system.





Block Digram Basics Summing junction

Mechatronics

David Goodwi

Control system

Open-loop control Closed-loop control Example


PID controller

Step Response

Matlab & Octave

Resources

- A summing junction is represented by a circle.
- The input signals are signed (can be + or -) and the sign with which they are added to the output is displayed on the signal line leading to the junction.
 - C = A + (-B)
 - A is a signed input, B is a signed input, and C is the output.





Block Digram Basics

Mechatronics

David Goodwi

Control systems

Open-loop control Closed-loop control Example

System Respons
PID controller

Step ivesponse

Matlab & Oc

- The 2 blocks in series (also known as cascade blocks) can be combined (multiplication) into a single block as long as there is nothing between them.
 - The way these two blocks were combined is only valid for SISO (single input single output) systems.





Block Digram Basics Parallel blocks

Mechatronics


The 2 blocks in parallel can be combined (added) into a single block as long as there is nothing between them.

$$X(s) \xrightarrow{G_a(s)} Y(s) \xrightarrow{Y(s)} Y(s) \xrightarrow{Y(s)} Y(s)$$



Open-loop control

Mechatronics





Open-loop control


Mechatronics

David Goodwi

Open-loop contro Closed-loop contro Example

System Response
PID controller
Step Response

Matlab & Octav



- Then the resulting Loop Transfer Function can be found by inspection:
- Open-loop transfer function $=\frac{y}{r}=GK$
- The Open-Loop Transfer Function is GK which appears to be backwards given that the blocks appeared as KG when the system is read left to right.
- For SISO systems the order is arbitrary. However, for MIMO systems this backwards order must be maintained.
- This is because the system is represented with matrices and in Linear Algebra (matrix math) the order of execution is vital - there is no Commutative property for matrix multiplication.



Mechatronics


David Goodwir

Control systems
Open-loop control
Closed-loop contro

System Response

Matlah & Octave

iviatiab & Octav





Mechatronics


David Goodwii

Control systems
Open-loop control
Closed-loop control
Example

System Responses
PID controller
Step Response

Matlab & Octave

Resources



- The Closed Loop Transfer Function is
- $y = GKe = GK(r y_m)$
- where $y_m = Hy$





Mechatronics

David Goodwii

Control systems

Open-loop control


Closed-loop contro

Example

System Response
PID controller
Step Response

Matlab & Octav

Matian & Octave



$$y = GK(r - Hy)$$

$$= GKr - GKHy$$

$$y + GKHy = GKr$$

$$(1 + GKH)y = GKr$$

Closed-loop Tansfer Function =
$$\frac{y}{r} = \frac{GK}{(1 + GKH)}$$



Mechatronics

David Goodwii

Open-loop control

Closed-loop control

Example

System Response
PID controller
Step Response

Matlab & Octave

Closed-loop Tansfer Function $= \frac{y}{r} = \frac{GK}{(1 + GKH)}$

- The numerator is the forward (open-loop) gain from r to y.
- The denominator is one plus the gain in going around the feedback loop, the so-called loop gain.
 - If $|GK|\gg 1$, and if $|H|\approx 1$, then y is approximately equal to r and the output closely tracks the reference input.



An example of Closed-loop systems control Disk drive read system

Mechatronics

David Goodwin

Control systems
Open-loop contro
Closed-loop contr


Exampl

System Response
PID controller
Step Response

Matlab & Octave

Department of Computer Science and Technology University of

Bedfordshire





David Goodwi

Control systems
Open-loop contro
Closed-loop cont

System Response PID controller Step Response

Matlab & Octave Resources

An example of Closed-loop systems control Disk drive read system

- A hard disk uses round, flat disks called platters, coated on both sides with a special media material designed to store information in the form of magnetic patterns.
- The platters rotate at high speed, driven by a special spindle motor connected to the spindle.
- Special electromagnetic read/write devices called heads are mounted onto sliders and used to either record information onto the disk or read information from it.
- The sliders are mounted onto arms, all of which are mechanically connected into a single assembly and positioned over the surface of the disk by a device called an actuator.
- A logic board controls the activity of the other components and communicates with the rest of the computer.



An example of Closed-loop systems control Disk drive read system

Mechatronics

David Coodwi

Control systems

Open-loop control

Closed-loop control


Example

System Responses

Matlab & Octave

IVIATIAD & OCTAVE

• We can model the system as a closed-loop control system





David Goodwin

Open-loop control
Closed-loop contro

System Response

PID controller

Matlah & Octavo

Resources

System Responses



System Responses Controllers

Mechatronics

David Goodw

Control systems
Open-loop control
Closed-loop contro
Example

System Responses

PID controller Step Response

Matlab & Octav

.

- To satisfy our design criteria we might need to apply feedback to our open loop system.
- Engineers use basically four techniques to achieve this. These techniques are::
 - PID
 - Root-locus
 - Frequency response
 - State space
- Controllers are not magic. It should not be assumed that every system can be controlled or that desired performance can be achieved for any given system if only the correct controller were employed. Proper system design is always required.



PID controller A generic controller

Mechatronics

David Goodwi

Control systems
Open-loop contro
Closed-loop contr

System Response

PID controller

Step Response

Matlab & Octave Resources

- A Proportional-Integral-Derivative controller (PID controller) is a generic controller widely used in industrial control systems.
- The PID control equation involves three separate parameters;
 Proportional term responds instaneously to the current error (providing instaneous response)

Integral term - responds to the accumulation of errors (providing a slow response that drives the steady-state error towards 0)

Derivative term - responds to the rate at which the error is changing (providing some anticipatory response)

Their respective weighting determines the controls response.



PID controller

A generic controller

Mechatronics


David Goodwir

Control systems
Open-loop control
Closed-loop control
Example

System Responses
PID controller

Matlab & Octave

Matlab & Octave



• PID control combines proportional control, integral control, and derivative control in parallel.

$$K = k_p e(t) + k_i \int e(t)dt + k_d \frac{e(t)}{dt}$$



PID controller

Schematic with Op Amps

Mechatronics


David Goodwir

Control systems Open-loop contro Closed-loop contr

System Response
PID controller

Matlab & Octave

Matlab & Octave





David Goodwi

Control systems Open-loop control Closed-loop contro Example

PID controller

Step Response

Resources

Step Response A test for system stability

- Step response is the time behaviour of the outputs of a general system when its inputs change from zero to one in a very short time.
- knowing how the system responds to a sudden input is important because large and possibly fast deviations from the long term steady state may have extreme effects on the component itself.
- The overall system cannot act until the component's output settles down to some vicinity of its final state, delaying the overall system response.
- Knowing the step response of a dynamical system gives information on the stability of such a system, and on its ability to reach one stationary state when starting from another.
- http://www.youtube.com/watch?v=cNZPRsrwumQ shows a good example of a step response (around 35 second into the video when the robot is kicked from the side).



Step Response A test for system stability

Mechatronics

The step response can be described by the following quantities related to its time behavior:

Overshoot - refers to an output exceeding its final, steady-state value

Rise time - time taken by a signal to change from a specified low value to a specified high value

Settling time - the time required for the response curve to reach and stay within a range of certain percentage (usually 5% or 2% - characterised by the ringing, see below) of the final value.

Ringing - unwanted oscillation of a signal, closely related to overshoot, generally occurring following overshoot. This is characterised by the steady-state error (S-S error)



Effects on controller parameters


Mechatronics

The effects of each of controller parameters, K_p , K_d , and K_i on a closed-loop system are summarized in the table below.

K RESPONSE	RISE TIME	OVERSHOOT	SETTLING TIME	S-S ERROR
$K_p \ K_i \ K_d$	Decrease Decrease Small Change	Increase Increase Decrease	Small Change Increase Decrease	Decrease Eliminate No Change



Computer Science and University of Bedfordshire





MATLAB with Control System Toolbox

Mechatronics

David Goodwi

Control systems
Open-loop control
Closed-loop contro
Example

System Response

Matlab & Octave

- Numerical computation, visualization, and programming.
- Analyze data, develop algorithms, and create models and applications.
- The language, tools, and built-in math functions enable you to explore multiple approaches and reach a solution faster than with spreadsheets or traditional programming languages, such as C/C++ or Java.
 - Control System Toolbox provides industry-standard algorithms and tools for systematically analyzing, designing, and tuning linear control systems.
 - Transfer function, state-space, pole-zero-gain, or frequency-response model.



GNU Octave compatible with MATLAB

Mechatronics

David Goodwi

Control systems
Open-loop control
Closed-loop contro

System Responsible Step Responsi

Matlab & Octave

Resources

- GNU Octave is a high-level language for numerical computations.
- Language is mostly compatible with MATLAB.
- As part of the GNU Project, it is free software under the terms of the GNU General Public License (GPL).
 - The Octave language is an interpreted programming language. It is a structured programming language (similar to C) and supports many common C standard library functions, and also certain UNIX system calls and functions.
 - Octave programs consist of a list of function calls or a script.
 - The syntax is matrix-based and provides various functions for matrix operations. It supports various data structures and allows object-oriented programming.
 - Syntax is very similar to MATLAB, and careful programming of a script will allow it to run on both Octave and MATLAB.
 - Can be used together with QtOctave to gave a MATLAB-like IDE.



David Goodwin

. . .

Open-loop control Closed-loop control

ystem Response

PID controlle

Matlah P. Octavo





Resources Useful literature

Mechatronics

David Goodw

Control systems
Open-loop control
Closed-loop control
Example

System Respo PID controlle Step Respons

Matlab & Octa

- R. Manchini (2002) Op Amps for everyone:
 http://www.ti.com/lit/an/slod006b/slod006b.pdf
- ControlTheoryPro.com (2012) http://wikis. controltheorypro.com/index.php?title=Main_Page
- Op Amp PID controller scematics http://www. ecircuitcenter.com/Circuits/op_pid/op_pid.htm
- MATLAB community http://www.mathworks.co.uk/matlabcentral/including forums, file exchange, and full documentation on syntax (http://www.mathworks.co.uk/help/matlab/)



David Goodw

Control systems Open-loop contro Closed-loop contr Example

Step Response

Matlab & Octav

Resources

GNU Octave Setup instructions for windows

- Download Octave from http://octave.en.softonic.com/download and run the exe, then follow the instructions from the wizard.
- Download qtoctave, I got mine from http://www.outsch.org/wp-content/uploads/2011/01/ qtoctave-0.10.1-win32.zip
- Open qtocatve, select config; general configuration from the drop down menu at the top of the window, then select the octave menu
- In the octave path click select, then navigate to where you installed octave then select the octave.exe in the bin folder
- Create a working directory, where ocatve will search for your .m files to run (this is important)