AUDIO VISUAL GUIDE

To turn on the Projector please press once and wait for the button to stop flashing.

Select the source you require

Use the TRANSPORT controls for VHS and DVD playback.

Use the DVD MENU controls to navigate the DVD menu structure



You can control the VOLUME with these buttons

WHEN USING YOUR OWN LAPTOP

Please connect the fly leads



Network cable to enable Novell Login / Internet Access.

VGA cable to display your laptop through the projector.

Audio Jack to connect to the room's audio system (connect to your laptop's headphone socket and ensure volume is turned up)

Please note you may need to hold the Fn key and press the F5 key to output the signal from your laptop

For further help or guidance please contact Audio Visual Services on 024 765 (22463)